ASSEMBLY INSTRUCTIONS

ITEM NO: BO-3157FL

1.Place the **Lamp Base** in an upright position on the floor, be sure the power to the installation point is power off.

2.Thread **Part B** to the **Base** as shown. Hand tighten until snug.

3.Locate the **Harp** by pressing the bottom ends of the **Harp** into the **Saddle**.

4.Place the center hole on the top of the Shade over the nipple at the top end of the **Harp**. Secure the Shade by threading the Finial onto the **Harp**. Hand tighten until snug.

5.Install correct **Bulb** referring to fixture markings and /or labels for maximum wattage.USE 150W (MAXIMUM) 3-WAY TYPE A
BULB (BULB NOT INCLUDED)



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.